

ROSWELL

WAKE-BOARD

RWA MOTION SWIVEL INSTRUCTIONS

Tools Needed: 3/16" Allan Wrench

NOTE

All bolts must be tightened using permanent lock- tite

You will most likely be attaching the RWA motion swivel to our universal clamp- Please see universal clamp instructions for adjustments to the clamp angle.

You can attach the clamp to the tower and then start these instructions or completes steps 1-4 and then attach the entire swivel-boardrack assembly to the tower.

1. Open the contents of the box- You will start by attaching the adaptor plate with the four shorter socket head cap screws to the 1/4" inserts on the universal clamp.



2. Line up the swivel block with the open inserts on the adaptor plate from step one. You may need to rotate the swivel 90 degrees to access the holes.



3. With the swivel lined up you can attach the swivel block to the clamp and adaptor with the 4 longer bolts. You want the swivel button to be on the underside of the assembly. Please ensure that you follow the X pattern outlined below.



4. With the swivel and clamp together you can now attach the board rack to the assembly. Line up your boardrack with the inserts on the female side of the swivel and tighten.

