

# ROSWELL

WAKE-BUR

## S.I. MANUAL SWIVEL INSTRUCTIONS

**Tools Needed: 3/16" Allan Wrench**

**\*NOTE\***

**All bolts must be tightened using permanent lock- tite**

**You will most likely be attaching the RWA motion swivel to our universal clamp- Please see universal clamp instructions for adjustments to the clamp angle.**

**You can attach the clamp to the tower and then start these instructions or completes steps 1-4 and then attach the entire swivel-boardrack assembly to the tower.**

1. Open the contents of the box- You will start by attaching the adaptor plate with the four shorter socket head cap screws to the 1/4" inserts on the universal clamp.



2. Line up the swivel block with the open inserts on the adaptor plate from step one. You may need to rotate the swivel 90 degrees to access the holes.



3. With the swivel lined up you can attach the swivel block to the clamp and adaptor with the 4 longer bolts. You want the swivel to be oriented with the center shoulder bolt on the top side as the above picture illustrates. Please ensure that you follow the X pattern outlined below.



4. With the swivel block and clamp together you can now insert the Q.R. pin. Start by looping the lanyard around the round end of the swivel. Put the Q.R. Pin in position as shown below.



5. With the lanyard looped around the swivel you can line up your board rack with the swivel inserts and tighten all four bolts. (supplied with rack)

